

## RS26/RS32/RS32L




















## RS26/RS32/RS32L

## Important:


Before doing any maintenance on the scrubber, be sure the power is turned OFF or the batteries are disconnected.


Fill solution tank with water (not to exceed 60 /140 .Pour a recommended cleaning detergent into the solution tank according to mixing instructions on the container)

Wet Flooded Battery



Follow the battery manual for the wet batteries maintenance, Keep Battery Compartment Open When Charging. Clean and Check the Connection tight of Battery Terminal.





Check battery fluid level frequently to prevent battery damage. Add distilled water if low. DO NOT OVERFILL, the fluid may expand and overflow when charging.







When cleaning batteries, wear protective gloves and eye protection. Avoid contact with ba ttery acid. Fire Or Explosion Hazard. Batteries Emit Hydrogen Gas. Keep Sparks and Open Flame A way.

