
TABLE OF CONTENTS

1、 RECOVERY TANK GROUP	1
RECOVERY TANK COVER SEAL(8131005){i20NB 000165~001099、 i20NBT 000187~000776、 i20NBT-OB 000101~000409、 i24BT 000139~000482}.....	2
RECOVERY TANK COVER SEAL(8131005-2){i20NB 001100~、 i20NBT 000777~、 i20NBT-OB 000410~、 i24BT 000483~ }.....	2
CAP(8131003){i20NB 000165~101687、 i20NBT 000187~102033、 i20NBT-OB 000101~100931、 i24BT 000139~100925}.....	2
CAP(8131004){i20NB 101688~、 i20NBT 102034~、 i20NBT-OB 100932~、 i24BT 100926~ }.....	2
DRAIN HOSE(8131010){i20NB 000165~101273、 i20NBT 000187~101231、 i20NBT-OB 000101~100609、 i24BT 000139~000611}.....	2
DRAIN HOSE(8210170)No record.....	2
DRAIN HOSE(8131030){i20NB 101274~101658、 i20NBT 101232~101983、 i20NBT-OB 100610~100878、 i24BT 100612~100874}.....	2
DRAIN HOSE(8131031){i20NB 101659~、 i20NBT 101984~、 i20NBT-OB 100879~、 i24BT 100875~ }.....	2
2、 VACUUM FAN GROUP	4、 6、 8
VACUUM MOTOR, KIT, 24VDC(8116500){i20NB 000165~000490/101604~、 i20NBT 000187~000425/101868~、 i20NBT-OB 000101~000222/100789~、 i24BT 000139~000281/100835~}.....	5、 7、 9
VACUUM MOTOR, KIT, 24VDC(8132050){i20NB 000528~101254、 i20NBT 000439~001230、 i20NBT-OB 000229~000608、 i24BT 000282~100612}.....	5、 7、 9
BRACKET(8112003){i20NB 000165~001070、 i20NBT 000187~000881、 i20NBT-OB 000101~000410、 i24BT 000139~000492}.....	5、 7
3、 SOLUTION TANK GROUP	10
CLEAN TUBING(8133008){i20NB 000729~、 i20NBT 000641~、 i20NBT-OB 000294~、 i24BT 000362~}.....	11
4、 CONTROL CONSOLE GROUP(i20NB1.0)	13
CONTROL CONSOLE HOUSING(8134001){i20NB 000165~000490}.....	14
PCB ASSEMBLY(8114701){i20NB 000165~000247}.....	14
CONTROL PANEL(8134010){i20NB 000165~000490}.....	14

TABLE OF CONTENTS

CONTROL PANEL DECAL, i20NB(8134014){i20NB 000165-000490}.....	14
CIRCUIT BREAKER, 5A(8114703){i20NB 000165-000247}.....	14
CABLE, SQGE LIFT(8134013){i20NB 000165-000490}.....	14
CLAMP, DRAIN HOSE(6210111){i20NB 000165-101503}.....	14
LEVER, BAIL(8134300){i20NB 000905~ }.....	15
REAR PLATE, CONTROL CONSOLE(8134021){i20NB 000165-000490}.....	15
SOLENOID SWITCH(8124704){i20NB 000165-000247}.....	15
RELAY, 40A(8114707){i20NB 000165~ }.....	15
5、 CONTROL CONSOLE GROUP(i20NB1.5).....	16
CONTROL CONSOLE HOUSING(8134001){i20NB 000165-000490}.....	17
PCB ASSEMBLY(8134702){i20NB 000271-000490}.....	17
CONTROL PANEL(8134010){i20NB 000165-000490}.....	17
CONTROL PANEL DECAL, i20NB(8134014){i20NB 000165-000490}.....	17
CIRCUIT BREAKER, 5A(8310740){i20NB 000905~ }.....	17
CABLE, SQGE LIFT(8134013){i20NB 000165-000490}.....	17
CLAMP, DRAIN HOSE(6210111){i20NB 000165-101503}.....	17
LEVER, BAIL(8134300){i20NB 000905~ }.....	18
MAIN CONTROLLER(8134701){i20NB 000271-000490}.....	18
REAR PLATE, CONTROL CONSOLE(8134021){i20NB 000165-000490}.....	18
6、 CONTROL CONSOLE GROUP(i20NB2.0).....	19
CONTROL PANEL DECAL, i20NB(8134724){i20NB 000694~ }.....	20
CONTROL PANEL, i20NB(8134720){i20NB 000804~ }.....	20
CONTROL PANEL PCB, i20NB (AGM / EN)(8134734){i20NB 000905~ }.....	20
CONTROL HOUSING(8134005A){i20NB 000905~ }.....	20
CIRCUIT BREAKER, 5A(8310740){i20NB 000905~ }.....	20

TABLE OF CONTENTS

PLATE, ON BOARD BATTERY CHARGER(8134060){i20NB 000905~ }	20
ON-BOARD CHARGER SPE 13-amp 24 volt,KIT(8132010-US){i20NB 000165~000999}	20
ON-BOARD CHARGER Pro CHARGING SYSTEM 13-AMP 24 VOLT (OPTION) (8132010-US){i20NB 000165~000999}	20
ON BOARD CHARGER Pro CHARGING SYSTEM 13-AMP 24 VOLT (OPTION) (8132020-US){000165~000999}	20
ON-BOARD CHARGER FLEXCHAR, PRESET Trojan CHARGING CUVE(OPTION),KIT(8132015A){No record}	20
BATTERY CHARGER POWER CORD, KIT(8112030A){i20NB 000905~}	20
CAR CHARGER(SPE)(8132010){i20NB 000165~000999}	20
ON-BOARD CHARGER SPE 13-amp 24 volt(8132010A){No record}	20
ON-BOARD CHARGER FLEXCHAR(8132015-US){No record}	20
CABLE, SQGE LIFT(8134082){i20NB 000905~、 }	20
CLAMP, DRAIN HOSE(6210111){i20NB 000165~101503}	21
CLAMP, DRAIN HOSE(6210120){i20NB 101504~}	21
MAIN CONTROLLER, i20NB(8134790){i20NB 000905~ }	21
REAR PLATE, CONTROL CONSOLE(8134070){i20NB 000905~ }	21
LEVER, BAIL(8134300){i20NB 000905~ }	21
(21)CONTROL BOX BACK SEALING RING(8134085){i20NB 101666~ }	21
(22)CONTROL BOX SEAL RING(8134083){i20NB 101652~ }	21
7、 CONTROL CONSOLE GROUP(i20NBT /i24BT1.0)	22
CONTROL CONSOLE HOUSING (8134001){i20NBT 000187~000603、 i20NBT-OB 000101~000288、 i24BT 000139~000321}	23
PCB ASSEMBLY(8124701){i20NBT 000187~000603、 i20NBT-OB 000101~000288、 i24BT 000139~000321}	23
CONTROL PANEL (8144010){i20NBT 000187~000603、 i20NBT-OB 000101~000288、 i24BT 000139~000321}	23
CONTROL PANEL DECAL, i20NBT(8144014){i20NBT 000187~000628、 i20NBT-OB 000101~000288}	23

TABLE OF CONTENTS

CONTROL PANEL DECAL, i24BT(8144015){i24BT 000139-000321}.....	23
BUTTON,EMERGENCY STOP(8124007){i20NBT 000187-001030、 i20NBT-OB 000101-000435、 i24BT 000139-000532}.....	23
SPRING(8124008){i20NBT 000187-001030、 i20NBT-OB 000101-000435、 i24BT 000139-000532}.....	23
BASE, CIRCUIT BREAKERS MNTG(8144030){i20NBT 000187-001030、 i20NBT-OB 000101-000435、 i24BT 000139-000532}.....	23
CIRCUIT BREAKER, 35A(8114703){i20NBT 000187-000603、 i20NBT-OB 000101-000288、 i24BT 000139-000321}.....	23
EMERGENCY STOP SWITCH, KIT(8124715A){i20NBT 000187-001030、 i20NBT-OB 000101-000435、 i24BT 000139-000532}.....	23
CLAMP, DRAIN HOSE(6210111){i20NBT 000187-101635、 i20NBT-OB 000101-100728、 i24BT 000139-100692}.....	24
SPEED CONTROL BOARD(8124501){i20NBT 000187-000603、 i20NBT-OB 000101-000288、 i24BT 000139-000321}...	24
LEVER, BAIL(8134300){i20NBT 000681~ 、 i20NBT-OB 000294~ 、 i24BT 000433~ }.....	24
REAR PLATE, CONTROL CONSOLE(8134021){i20NBT 000187-000603、 i20NBT-OB 000101-000288、 i24BT 000139-000321}.....	24
SOLENOID SWITCH(8124704){i20NBT 000187-000603、 i20NBT-OB 000101-000288、 i24BT 000139-000321}.....	25
RELAY, 40A(8114707){i20NBT 000187~ 、 i20NBT-OB 000101~ 、 i24BT 000139~ }.....	25
8、 CONTROL CONSOLE GROUP(i20NBT /i24BT2.0).....	26
CONTROL PANEL DECAL, i20NBT(8144724){i20NBT 000604~ 、 i20NBT-OB 000294~ }.....	27
CONTROL PANEL DECAL, i24BT(8144725){i24BT 000321~ }.....	27
CONTROL PANEL, i20NBT (8144720){i20NBT 000604~ 、 i20NBT-OB 000294~ }.....	27
CONTROL PANEL PCB, i20NBT (AGM / EN)(8144795){i20NBT 000681~ 、 i20NBT-OB 000294~ 、 i24BT 000433~ }.....	27

TABLE OF CONTENTS

CONTROL PANEL PCB, i20NBT (WET FLOODED / EN)(8144797){No record}.....	27
CONTROL HOUSING, i20NB(8134005A){i20NBT 000681~、i20NBT-OB 000294~、i24BT 000433~ }	27
CIRCUIT BREAKER, 5A(8310740){i20NBT 000681~、i20NBT-OB 000294~、i24BT 000433~ }	27
BASE, EMERGENCY STOP SWITCH(8134007){i20NBT 001031~、i20NBT-OB 000436~、i24BT 000533~ }	27
LABEL, EMERGENCY STOP SWITCH(8144027){i20NBT 001031~、i20NBT-OB 000436~、i24BT 000533~ }	27
BUTTON,EMERGENCY STOP(8310707){i20NBT 001031~、i20NBT-OB 000436~、i24BT 000533~ }	27
PLATE, ON BOARD BATTERY CHARGER(8134060){i20NBT 000681~、 i20NBT-OB 000294~、i24BT 000433~ }	28
ON-BOARD CHARGER SPE 13-amp 24 volt,KIT(8132010-US){i20NBT 000187~000850、 i20NBT-OB 000101~000410、i24BT 000139~000482}	28
ON-BOARD CHARGER FLEXCHAR, PRESET Trojan CHARGING CUVE(OPTION),KIT(8132015A){No record}	28
ON BOARD CHARGER Pro CHARGING SYSTEM 13-AMP 24 VOLT, KIT (OPTION) (OPTION)(8132020-US) {i20NBT 000187~000850、i20NBT-OB 000101~000410、i24BT 000139~000482}	28
BATTERY CHARGER POWER CORD, KIT(8112030A){i20NBT 000681~、 i20NBT-OB 000294~、i24BT 000433~ }	28
CAR CHARGER(SPE)(8132010){i20NBT 000187~000850、i20NBT-OB 000101~000410、 i24BT 000139~000482 }	28
ON-BOARD CHARGER SPE 13-amp 24 volt(8132010A){i20NBT 000187~000850、 i20NBT-OB 000101~000410、i24BT000139~000482 }	28
ON BOARD BATTERY CHARGER, INCLUDE TERMINAL, FLEXCHAR(8132015-US){No record}	28
CABLE, SQGE LIFT(8134082){i20NBT 000681~、i20NBT-OB 000294~、i24BT 000433~ }	28
CLAMP, DRAIN HOSE (6210111){i20NBT 000187~101635、i20NBT-OB 000101~100728、i24BT 000139~100692 }	29
(21)MAIN CONTROLLER, i20NBT(8144790){i20NBT 000604~、i20NBT-OB 000294~、i24BT 000321~ }	29
(22)REAR PLATE, CONTROL CONSOLE(8134070){i20NBT 000618~、i20NBT-OB 000294~、i24BT 000433~ }	29
(23)LEVER, BAIL(8134300){i20NBT 000618~、i20NBT-OB 000294~、i24BT 000433~ }	29

TABLE OF CONTENTS

(24)CONTROL BOX BACK SEALING RING(8134085){i20NBT 102014~、i20NBT-OB 100917~、i24BT 100882~ }	29
(25)CONTROL BOX SEAL RING(8134083){i20NBT 101959~、i20NBT-OB 100841~、i24BT 100868~ }	29
9、 FRAME&WHEEL GROUP(i20NB1.0)	30
MAIN FRAME(8135100){i20NB 000165~000490}	31
WHEEL, 8 INCH(8115200){i20NB 000165~ }	31
ADAPTER, AXLE MNTG(8115402){i20NB 000165~000490 }	31
MICRO SWITCH 25A(8115007){i20NB 000165~000490}	31
SOLENOID VALVE, 24VDC(8119003){i20NB 000165~ }	31
10、 FRAME&WHEEL GROUP(i20NB2.0)	33
MAIN FRAME(8145100){i20NB 000433~ }	34
SOLENOID VALVE, 24VDC(8119003){i20NB 000165~ }	34
WHEEL, 8 INCH(8115200){i20NB 000165~ }	34
S H A F T (8 1 3 5 4 0 5) { i 2 0 N B 0 0 0 4 3 3 ~ }	34
MICRO SWITCH 20A(8014071){i20NB 000433~ }	35
SLEEVE, P/M(8115405){i20NB 000165~ }	35
11、 FRAME&TRANSAXLE GROUP(i20NBT/i24BT1.0)	36
MAIN FRAME(8135100){i20NBT 000187~、i20NBT-OB 000101~、i24BT 000139~}	37
SOLENOID VALVE, 24VDC(8119003){i20NBT 000187~、i20NBT-OB 000101~、i24BT 000139~ }	37
WHEEL, 8 INCH(8125200){i20NBT 000187~、i20NBT-OB 000101~、i24BT 000139~ }	37
TRANSAXLE, KIT(8125410){i20NBT 000187~101887 / 102107~、i20NBT-OB 000101~100808/100955~、 i24BT 000139~100846/100942~}	37
BRACKET(8115009){i20NBT 000187~、i20NBT-OB 000101~、i24BT 000139~ }	38
CAP, MICRO SWITCH, 3/8(8115008){i20NBT 000187~000279、i20NBT-OB 000101~000222、i24BT 000139~000490}....	38
MICRO SWITCH 25A(8115007){i20NBT 000187~000394、i20NBT-OB 000101~000170、 i24BT 000139~No record}	38

TABLE OF CONTENTS

12、FRAME&TRANSAXLE GROUP(i20NBT/i24BT2.0).....	39
MAIN FRAME(8135100){i20NBT 000187~、 i20NBT-OB 000101~ 、 i24BT 000139~}.....	40
SOLENOID VALVE, 24VDC(8119003){i20NBT 000187~、 i20NBT-OB 000101~、 i24BT 000139~ }.....	40
WHEEL, 8 INCH(8125200){i20NBT 000187~、 i20NBT-OB 000101~ 、 i24BT 000139~ }.....	40
TRANSAXLE, KIT(8125410){i20NBT 000187~101887 / 102107~ 、 i20NBT-OB 000101~100808/100955~、 i24BT 000139~100846/100942~}.....	40
TRANSAXLE, KIT(8125408){i20NBT 101888~102106、 i20NBT-OB 100809~100954、 i24BT 100847~100941}.....	41
MICRO SWITCH 20A(8014071){i20NBT 000404~、 i20NBT-OB 000171~、 i24BT 000272~}.....	41
SLEEVE,PM(8115405){i20NBT 000187~、 i20NBT-OB 000101~、 i24BT 000139~ }.....	41
13、 SCRUB HEAD GROUP (i20NB / i20NBT).....	42
KEY(1656432){No record}.....	43
KEY(1656433){i20NB 000985~ 、 i20NBT 000831~ }.....	43
14、 SCRUB HEAD GROUP (i20NBT-OB1.0).....	45
LOCK, WEIGHT(8146106){i20NBT-OB 000101~000130}.....	46
BRACKET, ORBITAL HEAD(8146101){i20NBT-OB 000101~000288}.....	46
BRACKET, MOTOR MOUNTING(8146102){i20NBT-OB 000101~000288}.....	46
ELBOW, TUBING BARB(8119002){i20NBT-OB 000101~101019}.....	46
CLAMP(1962016){i20NBT-OB 000101~101019}.....	46
TUBING, ID=12mm, l=60mm(8146320){i20NBT-OB 000101~101019}.....	46
15、 SCRUB HEAD GROUP (i20NBT-OB2.0).....	47
MOTOR, 24VDC 550W 2200RPM, KIT(8146199){i20NBT-OB 000101~ }.....	48
MOUNTING BRACKET, ORBITAL HEAD(8146520){i20NBT-OB 000294~ }.....	48
BRACKET, MOTOR MOUNTING(8146501){i20NBT-OB 000294~ }.....	48
PVC TUBING (8146508){i20NBT-OB 000294~ }.....	48
PAD DRIVER(8146502){i20NBT-OB 000294~}.....	48
ELBOW, 3/8(8146511){i20NBT-OB 000294~}.....	48

TABLE OF CONTENTS

COUPLER(8119012){i20NBT-OB 000121~ }	48
SEALING CAP(8146208){i20NBT-OB 100776~ }	48
PAD(8146209){i20NBT-OB 100776~ }	48
16、 SCRUB HEAD GROUP (i24BT)	50
BRUSH MOTOR, 24VDC 680W 2000RPM, KIT(8126200){i24BT 000139~ }	51
11" PAD DRIVER(9040011U){i24BT 000482~ }	51
17、 SCRUB HEAD LIFT GROUP (i20NB / i20NBT)	53
BUMPER(8133151){i20NB 000528~ 、 i20NBT 000459~ }	54
18、 ORBITAL HEAD LIFT GROUP (i20NBT-OB1.0)	55
BUMPER(8133151){i20NBT-OB 000171~ }	56
19、 ORBITAL HEAD LIFT GROUP (i20NBT-OB2.0)	57
BUMPER(8133151){i20NBT-OB 000171~ }	58
BRACKET, ORBITAL HEAD LIFT(8146530){i20NBT-OB 000249~ }	58
20、 ORBITAL HEAD LIFT GROUP (i24BT)	59
BUMPER(8133151){i24BT 000287~ }	60
21、 SQUEEGEE GROUP(1.0)	61
RETAINER,SQUEEGEE(8118005){i20NB 000165~000490、 i20NBT 000187~000488、 i20NBT-OB 000101~000258、 i24BT 000139~000311}	62
VACUUM HOSE(8118006){i20NB 000165~101273、 i20NBT 000187~101231、 i20NBT-OB 000101~100609、 i24BT 000139~000611}	62
22、 SQUEEGEE GROUP(2.0)	63
STAINLESS STEEL RETAINER,SQUEEGEE(8118009){i20NB 000528~、 i20NBT 000489~ 、 i20NBT-OB 000259~ 、 i24BT 000337~ }	64
PLASTIC SPACER(8118008){i20NB 000528~、 i20NBT 000489~、 i20NBT-OB 000259~、 i24BT 000337~ }	64
VACUUM HOSE(8118006){i20NB 000165~101273、 i20NBT 000187~101231、 i20NBT-OB 000101~100609、 i24BT 000139~000611}	64

TABLE OF CONTENTS

23、 SOLUTION GROUP(S/N.XXXXXX-XXXXXX).....65

24、 WIRING DIAGRAM FOR {i20NB 000165-000270}.....67

25、 WIRING DIAGRAM FOR i20NBT, i20NBT-OB & i24BT
{SN.XXXXXX-XXXXXX}.....68

26、 WIRING DIAGRAM FOR {i20NB 000271~000527}.....69

27、 WIRING DIAGRAM FOR i20NBT, i20NBT-OB & i24BT
{i20NBT 000187~000603 I24BT 000139~000321}.....70

28、 WIRING DIAGRAM FOR {i20NB 000528~}.....71

27、 WIRING DIAGRAM FOR i20NBT, i20NBT-OB & i24BT
{i20NBT 000604~ i24BT 000322~}.....72